

500 Size Hygienic Stainless Steel FIP Pump

12/02

28620 Series

Hygienic Stainless Steel Head Kit Pump

- Self primes from dry up to 5.0 metres
- Flows up to 520 litres per minute
- Pressure up to 5.0 bar[†]
- · Handles soft solids max. 18mm diameter
- Certified to US 3A Standard 02-09
- Clean-In-Place (CIP) or easy strip clean
- Handles viscosities up to 10,000 centiPoise
- Minimal shear to thixotropic fluids
- Quick release end cover clamp

Typical Applications

- Foods, sauces, doughs, preserves, liquid egg, meat pastes
- · Dairy products, milk,cream, yoghurt, cheeses
- · Cosmetics, toothpaste, shampoos, soaps
- · Pharmaceutical creams & lotions
- · Wines, beers, soft drinks, fruit juices & syrups
- · Ingredients unloading and transfer
- Tank filling and emptying
- · Recirculation and mixing
- · Portion and container filling
- · Brine injection
- · Sampling, filtration and more



Specifications

Seal : Carbon / Stainless steel mechanical face Tungsten Carbide / Stainless steel hard faced Flushed options for crystalising fluids

Seal Elastomer: Food grade Nitrile O-rings

Pump Head: Stainless steel 316, machined interior and electropolished exterior finish

End Cover: Stainless steel 316 grade

Shaft: Stainless steel 316 grade special motor shaft

Bearings: Uses motor bearings

Motor Adaptor: Cast 316 grade Stainless steel

Ports

Weight: 15.0kg

:		Tri-Clamp	28620-1xxx
	63.5mm	IDF/ISS	28620-3xxx
	21/2"	RJT to BS1864	28620-4xxx
	21/2"	3A Bevel Seat	28620-5xxx
		DIN 11851	28620-6xxx
	63.5mm	SMS 1145	28620-7xxx

Model Range

Standard - Max 2.0 ba	r High - Max 5.0 bar [†]	High - Max 5.0 bar [†]	
3A Neoprene	3A Neoprene		
4°C to 65°C	4°C to 65°C		
	28620-x125		
	3A Neoprene	3A Neoprene 3A Neoprene 4°C to 65°C 4°C to 65°C	

For models not listed above, consult distributor or factory, 'x' Substitute port code from table above

Note: it is not recommended to start the pump at extremes of the temperature range, impeller damage may occur For Installation, Operating, Maintenance and Safety Instructions refer to form 43001-0543




Do not pump gasoline, solvents, thinners or other flammable liquids. To do so can cause an explosion resulting in injury or death.

† Pressures over 3.0 bar may reduce motor shaft life




500 Size Hygienic Stainless Steel FIP Pump

12/02



Parts List

Key	Description	Qty	Part Number		
2	Endcover	1	22007		
3	O-Ring *	2	See right		
4	Body	1	See right		
5	Impeller*	1	See right		
6	Wearplate	1	28606-0000		
7	Motor Adaptor	1	22254-0010		
8	Seal Assembly *	1	See right		
9	O-Ring	1	X4020-269A		
10	Adaptor Ring	1	28626-0000		
11	Seal Housing	1	28512-0000		
12	Tube	2	21844		
13	Seal	1	SP2701-0916		
14	Seal Sleeve	1	28627-0000		
15	O-Ring	1	X4020-237A		
16	Clamp Screw	1	21908		
17	Clamp Frame	1	21909-0000		
Dorto marked * Contained in coming bit					



Spare Parts & Service Kits

Pres	sure Ratin	ng	Standard	High
3	O-Ring	Nitrile	SP2000-1213	SP2000-1213
4	Impeller	3A Neoprene	8500-0005	21899-0005B
	Body	Tri-Clamp	22004-1001	22004-1001
		IDF/ISS	22004-3001	22004-3001
_		RJT	22004-4001	22004-4001
5		Bevel Seat	22004-5001	22004-5001
		DIN	22004-6001	22004-6001
		SMS	22004-7001	22004-7001
	Seals	Std Mech.	SP6080-0382	SP6080-0382
8		Hard Faced	SP3080-0390	SP6080-0390
Service Kit		3A Neoprene	SK395-0105	SK395-0125

Models use Nitrile elastomers on seals and O-rings.

NOTE:- Service Kits contain standard mechanical seals. For hard faced seals, order parts separately.

Other Available Options

Pedestal pumps, for higher pressure capabillity.

Jabsco



ITT Industries

USA

Jabsco

20 Icon Foothill Ranch CA 92610

Tel: +1 949 859 4945 Fax: +1 949 859 1153

UK

Jabsco

Bingley Road Hoddesdon Hertfordshire, EN11 OBU

Tel: +44 (0) 1992 450 145 Fax: +44 (0) 1992 467 132

GERMANY

Jabsco GmbH Oststraße 28 22844 Norderstedt

Tel : +49 (0) 40 53 53 73 0

Fax: +49 (0) 40 53 53 73 11