

Operating Instructions and Service Parts Guide


For the JABSCO® Porta-Quick Oil Changer

Model 17800-0000

Porta-Quick Oil Changer Operating Instructions

1. Run engine approx. 5 minutes to heat oil. (minimum oil temperature 140 degrees F.)
2. Push neoprene suction hose on pump inlet fitting.
3. Insert nylon suction probe into nipple on suction hose.
4. Clamp power cord alligator clips to 12 volt DC battery terminals, or 12 volt DC battery charger (minimum 5 Amp. Cap.).
Note: Attach red alligator clip to positive battery terminal.
5. Insert suction probe into dip stick tube until it bottoms.
6. Switch to "ON" position. Watch for oil flow through suction probe. If oil does not rise within 10 seconds, turn off pump, check suction probe for sediment blockage.
7. Motor will overspeed when oil has been pumped out of engine. Switch off motor pump immediately. Do not leave pump untended while pumping oil from engine. Normal 6 quart pump-out takes less than 3 minutes.
8. After oil has been pumped from engine, remove nylon suction probe from nipple and coil on lid of container for storage. Loop suction hose and secure to handle of container with chain hanger with nipple pointing up to prevent oil drippage. Coil power cord and secure to handle with chain hanger.
9. To empty container, pull up retractable pour spout and pour oil from container.

Service Parts List



Description	Part No.	Qty. Req.
* Impeller	1414-0003	1
* "O" Ring Gasket	92000-0750	1
* Seal	92700-0910	1
Motor (12 volt D.C.)	98012-0020	1
Power Cord, includes Switch & Clamps	93007-0490	1
Wire Connectors (terminal)	98022-0690	2
Pump Head	12317-0001	
Adaptor, Plastic	34378-0000	1
Adaptor, Rubber	33857-0000	1
40" Suction Probe	98022-1490	1

* Indicates parts included in Service Kit 90158-0003.

JABSCO PRODUCTS **ITT**

A Unit of International Telephone and Telegraph Corporation, 1485 Dale Way, Costa Mesa, California 92626
Telephone: (714) 545-8251